

DIRECTIONS FOR USE

FIL C3

MILKING MACHINES

1. After milking flush with a minimum of 10 litres of cold water per cluster.
2. Make up the normal hot (85°C) alkali detergent mix and add 15mL of C3 per 10 litres of wash solution.
3. For grade correction and/or as a pre-season heavy duty chlorinated alkali wash. Add C3 at 30mL per 10 litres of **alkali** wash solution.
4. Recirculate hot for 5-10 minutes, discard when temperature drops to 55°C
5. Follow with cold acid wash program.
6. For non-compliant water, add 5mL of C3 per 10 litres of wash solution.
7. Open plant to drain.

WATER TREATMENT

SHOCK TREATMENT – water with high microbial contamination

1. Add 1.5L of C3 per 1000L of water to give a chlorine level of 200ppm.
2. Allow a minimum of 8 hours contact time.
3. Rinse or pump through until the chlorine odour has disappeared.

POTABLE WATER

1. Add 10mL of C3 per 1000L of water.
2. Allow a minimum of 20 minutes for contact time.
3. Test water within 24 hours for residual chlorine – target 0.5ppm.
4. Adjust the dosing rate to ensure sufficient residual chlorine.

GENERAL CLEANING

1. Mix 3 parts water to 1 part C3.
2. Apply to concrete walls, floors etc, using a knapsack or other suitable low pressure spray apparatus.
3. Heavily soiled areas may require some scrubbing.
4. Allow C3 to work for approximately 10 minutes, then rinse thoroughly with water.

MOSS, MOULD ALGAE & LICHEN CONTROL (ROOFS, WALLS, PATHS, MASONRY)

1. Mix 3 parts water to 1 part C3.
2. Apply liberally to affected areas using a garden sprayer or watering can, using approximately 5 litres for every 10 square metres.
3. Leave for a minimum of 4 hours before scrubbing clean with a hard brush, then rinse with fresh water.
4. On vertical walls, apply using a garden sprayer from the top of the wall down.
5. Do not use immediately after rain, or if rain is likely within 6 hours of spraying.
6. Spray is harmful – take particular care when spraying in windy conditions.