

## DIRECTIONS FOR USE

### FIL Quantum XL

#### MILKING MACHINES – AFTER MILKING

1. Rinse plant with a minimum of 10 litres of cold water per cluster
2. Wash with hot water (85°C) containing 15 – 25mL of Quantum XL per 10 litres of water. Recirculate for 5 minutes, then discard when water temperature drops to 55°C
3. Rinse plant with cold water
4. Wash plant with a cold water acid solution following label instructions on one of the Quantum range of acid detergents
5. Ensure compliance with post-cleaning rinse requirements
6. Use complaint water only. It is recommended a Quantum XL wash be put through the milking plant twice weekly or more frequently if water quality of cleaning system requires it.

#### MILK SILO

1. Rinse silo with cold water to remove milk residues
2. Wash with hot water (85°C) containing 15 – 25mL of Quantum XL per 10 litres of water. Recirculate for 5 minutes, then discard when water temperature drops to 55°C
3. Rinse plant with cold water
4. Wash plant with a cold water acid solution following label instructions on one of the Quantum range of acid detergents
5. Ensure compliance with post-cleaning rinse requirements
6. Use compliant water only. It is recommended a Quantum XL wash be put through the milk silo twice weekly or more frequently if water quality or cleaning system requires it.